

**e***novation*  
simplifying life through technology and comfort

CORDLESS  
POWER MOTION  
PROGRAM



# FEATURES & BENEFITS

- 1 Year Warranty
- Charger included
- LED power indicator light
- Low power audible beep at 10% life
- 'Hard Shut Down' technology – battery enters sleep mode at 10%
- Power multiple motors on a single power pack (adaptors required)



# PRODUCT LINEUP



## E2 POWER PACK

### AT A GLANCE SPEC LIST:

- 2,000 mAh
- Up to 400 motorized functions (single charge)
- LED display and interactive low power alert



**\$149**



## E4 POWER PACK

### AT A GLANCE SPEC LIST:

- 3,800 mAh
- Up to 800 motorized functions (single charge)
- LED display and interactive low power alert



**\$199**

# PRODUCT LINEUP



## E6 POWER PACK

### AT A GLANCE SPEC LIST:

- 6,000 mAh
- Up to 1,200 motorized functions (single charge)
- LED display and interactive low power alert



Sofas and Small Sectionals



**\$249**



## E10 POWER PACK

### AT A GLANCE SPEC LIST:

- 10,000 mAh
- Up to 2,000 motorized functions (single charge)
- LED display and interactive low power alert
- Remote and manual on/off switch
- App available



Large Sectionals




**\$349**



# POWER MULTIPLE SEATS WITH A SINGLE POWER PACK

## enovation simplifying life through technology and comfort wiring guide

All Power Packs support components with or without power headrest.




Extension Cable = **RED CABLE**

Y Splitter = **BLUE CABLE**


Power Pack - **ORANGE CIRCLE**



### 2 SEAT SECTIONAL



### 3 SEAT SECTIONAL



- 1.) The power pack is equipped with an Interactive Low Power Alert that activates just before the pack reaches 10%. Pack will only beep when the furniture is being operated.
- 2.) Once the power pack reaches 10%, Hard Shut Down technology will disable ALL output and the pack will need to be recharged within 30 days.
- 3.) Only charge with the included Enovation charger. Pack requires 4-6 hours to fully charge.
- 4.) USB ports should not be used if furniture is powered with our power pack. This severely decreases the overall life of the product.
- 5.) If power pack is being used in a vacation home or second home, please disconnect, charge and store prior to departure. Power pack is capable of being stored for up to 6 months when fully charged and disconnected.

In the unlikely event that you need to file a claim, for prompt service please contact Enovation directly at:

[customer care@enovation.com](mailto:customer care@enovation.com) or by calling (213) 320-3265

## CARE:

- Batteries should be charged every 6 months, at store level and by customer
- Consumer should charge to 100% immediately upon arriving at residence (do not wait until furniture arrives)
- Power pack is not a battery in-line backup and should be the sole source of power
- Features that require constant power including lights, static touch buttons and USB ports (in use or not) can dramatically decrease function count and increase charge frequency
- Never intended for heat and massage
- If pack will be inactive for 30+ days in home, disconnect pack from furniture, charge and store in original box